

LillyTikes™

WARNING:
CHOKING HAZARD—Small parts.
Not for children under 3 years.


Lilly's Cook & Bake Kitchen™

AGES
3+

SKU: 654763

Includes:

- | | |
|-------------------|---------------------------------------|
| A. 2-in-1 Kitchen | G. Skillet |
| B. Cookie | H. Spatula |
| C. Cookie Sheet | I. Egg |
| D. 2 Teacups | J. Dog Bowl |
| E. 2 Plates | K. Doll Apron (dolls sold separately) |
| F. Teapot | L. Base Connector |





Illustrations are for reference only. Styles may vary from actual contents.

TRANSFORM FROM COMPACT TO EXPANDED KITCHEN

COMPACT



EXPANDED




1 Pull up on the countertop/kitchen wall to lift it off of the refrigerator and oven.



2 Remove the base connector from between the notched sides of the refrigerator and oven.



3 Store the base connector behind the refrigerator.



4 Slide the countertop/kitchen wall into the notches on the refrigerator base and oven base.

IMPORTANT INFORMATION

- Do not sit or stand on the surface of this kitchen to prevent possible injury.
- Thoroughly wash all accessories before contact with food or beverage.
- After use, empty all water from the teapot and teacups. Do not use anything except for clean, clear water with the included accessories.
- Spot clean the doll apron with mild detergent and clean water. Air dry only.
- Doll apron fits Lilly Tikes™ Lilly and Ami dolls, which are sold separately.

LIMITED WARRANTY

The Little Tikes Company makes fun, high quality toys. We warrant to the original purchaser that this product is free of defects in materials or workmanship for one year * from the date of purchase (dated sales receipt is required for proof of purchase). At the sole election of The Little Tikes Company, the only remedies available under this warranty will be the replacement of the defective part or replacement of the product. This warranty is valid only if the product has been assembled and maintained per the instructions. This warranty does not cover abuse, accident, cosmetic issues such as fading or scratches from normal wear, or any other cause not arising from defects in material and workmanship. *The warranty period is three (3) months for daycare or commercial purchasers.

U.S.A and Canada: For warranty service or replacement part information, please visit our website at www.littletikes.com, call 1-800-321-0183 or write to: Consumer Service, The Little Tikes Company, 2180 Barlow Road, Hudson OH 44236, U.S.A. Some replacement parts may be available for purchase after warranty expires—contact us for details.

Outside U.S.A and Canada: Contact place of purchase for warranty service. This warranty gives you specific legal rights, and you may also have other rights, which vary from country/state to country/state. Some countries/states do not allow the exclusion or limitation of incidental or consequential damages, so the above limitation or exclusion may not apply to you.

JOIN THE FUN at WWW.LILLYTIKES.COM

Please keep this manual as it contains important information.



© The Little Tikes Company, an MGA Entertainment company. LITTLE TIKES® is a trademark of Little Tikes in the U.S. and other countries. All logos, names, characters, likenesses, images, slogans, and packaging appearance are the property of Little Tikes.

Printed in China • 0420-0-E/INT



www.littletikes.com
www.littletikes.co.uk
www.littletikes.com.au

Little Tikes Consumer Service
2180 Barlow Road Hudson, Ohio 44236
U.S.A.
1-800-321-0183

MGA Entertainment UK Ltd.
50 Presley Way, Crownhill, Milton
Keynes, MK8 0ES, Bucks, UK
0800 521 558

MGA Entertainment (Netherlands) B.V.
Baronie 68-70, 2404XG
Alphen a/d Rijn, The Netherlands
Tel: +31 (0) 172 758038
E-mail: klantenservice@mgae.com

Imported by MGA Entertainment Australia Pty Ltd
Suite 2.02, 32 Delhi Road
Macquarie Park NSW 2113
1300 059 676